



ACRYLIC RESIN AND SHEET

Altuglas Medical Grade Acrylic Resins

ALTUGLAS
INTERNATIONAL
ARKEMA GROUP

Agenda



- **Relevant Trends in the Market**
 - Environmental Stress Crack (ESC) Resistance
 - Concerns over BPA
- **Overview of *Altuglas*® Medical Resins**
 - *Altuglas*® CR30
 - *Altuglas*® SG Grades
 - *Altuglas*® VS-UVT
- **Product Selection Guide**
 - Which Altuglas® grade is right for the application



Environmental Stress Cracking

Definition

Environmental Stress Cracking (ESC) is a phenomenon where a particular polymer cracks when in contact with a specific chemical agent while under stress¹



Polystyrene eyes
for soft toys



Polycarbonate
crash helmet



Styrene acrylonitrile
piano keys



Polyethylene
static oil tank

**~ 25% plastic part failures
are due to ESC**



Polycarbonate
pacifiers



Polymethyl methacrylate
small appliances



Why the Need to Improve ESC Resistance in Altuglas®?



- Drugs and disinfectants that contact devices are more aggressive than ever
- Devices in service for longer times
 - Increased potential for environmental stress cracking
 - More frequent replacement of device components
 - Increased risk for patients to acquire infections
- Regulatory “concerns” may limit the use of specific polymers
 - Altuglas® can fill this void



Why BPA Free?

Definition of BPA

Bisphenol-A is a monomer used to make certain plastics. It is produced by reacting phenol with acetone.

Regulatory bodies have expressed “Some Concern” with BPA

- *In 2010 the Canadian & European competent authorities imposed restrictions on BPA-based polycarbonate baby bottles¹*
- *In April 2008, National Toxicology Program (NTP) concluded that “exposure to BPA could be linked to developmental problems of the endocrine system in infants and young children”²*
- *The “some concern” about potential effects of BPA based on studies using novel approaches to test for subtle effects, which had been stated by FDA/NHIES in 2008, will be addressed by a specific FDA research program which is already ongoing³*

The outcome of this assessment could lead to regulation of BPA-containing medical devices





1. European Information Centre of BisPhenol A
2. Federal Register/Vol. 73. No. 200/Wednesday, October 15, 2008/Notices
3. www.fda.gov/downloads/AdvisoryCommittees/.../UCM176835.pdf

Altuglas® Medical Resins Provide a Balance of Properties

- Chemical resistance
- Optical clarity
- Resistance to gamma sterilization
- Welding options (ultrasonic welding, adhesives, & solvents)
- Ease of melt processing

And Regulatory Compliance

- USP Class VI approved
- ISO 10993 Parts 4 & 5 (cytotoxicity, hemolysis)
- Device Master Files
- Zero BPA or plasticizers
- No solvent concerns



Altuglas® Medical Product Range



- ➔ Chemical Resistance
- ➔ High Flow
- ➔ UV Transmitting
- ➔ Altuglas® Product Selection

Altuglas® CR30

Altuglas® SG7, Altuglas® SG10

Altuglas® VS-UVT

Comparative Advantages





Chemical Resistance

Altuglas® CR30



High Flow

Altuglas® SG7, Altuglas® SG10



UV Transmitting

Altuglas® VS-UVT




Altuglas® Product Selection

Comparative Advantages



Altuglas® CR30

- The next generation impact acrylic medical polymer offers an optimized balance of properties required for transparent disposable medical devices



Altuglas® CR30 provides performance and durability

Properties

- Resistance to environmental stress cracking (ESC)
- Good optics
- Resistance to sterilization
 - Gamma
 - e-beam
 - Ethylene oxide
- Good melt processing characteristics




How Is ESC Resistance Measured?



Elongation Retention After Exposure to Select Chemicals

- Annealed tensile bars exposed to chemical @ constant strain for given time
- Measure elongation at break
- Reported as % retention




Lipid Resistance of Altuglas® CR30




Exposure to Liposyn® III 20% for 24 Hours


- 1% constant strain



Resistance to Lipid (Liposyn® III)



- Annealed tensile bars exposed to chemical for 24 hrs at 1% constant strain
- Medical Grade Copolyesters severely crazed upon exposure-Test discontinued



Lipid Resistance of Altuglas® CR30




Exposure to Cremophor® RH40 for 24 Hours


- 1% constant strain



Resistance to Lipid (Cremophor® RH40)



- Annealed tensile bars exposed to chemical for 24 hrs at 1% constant strain
- Medical Grade Copolyesters severely crazed upon exposure-Test discontinued



IPA Resistant of Altuglas® CR Series

Exposure to 70% IPA/H₂O for 6 Hours

- 0.75 % constant strain




Resistance to 70% IPA

% Elongation retention

80
40
0Altuglas®
CR30Chem. Res.
Acrylic-Styrene
MultipolymerLipid Resistant
Polycarbonate

CoPolyester

Severely
Crazed

- Annealed tensile bars exposed to chemical for 6 hrs at 0.75% constant strain
- Medical Grade Copolyesters severely crazed upon exposure - Test discontinued

IPA = Isopropyl Alcohol

Presentation to Terumo Europe – 3/10/2011

Constant Strain Test – Time to Failure

- 2% constant strain
- Exposure to chemical mixture
- 👍 ESC resistance if no crazing within 1 hour



	Strong Base (NaOH pH=11)	Strong Acid (HCl pH=3)	Betadine®	Hibiclens®
Altuglas® CR30	👍	👍	👍	👍
Chem. Res. Acrylic Styrene Multipolymer	👍	👍	👍	👍
Lipid Resistant Polycarbonate	👎	👍	👍	👍
CoPolyesters	👍	👎	NA	NA



Properties

- Resistance to environmental stress cracking (ESC)
- Good optics
- Resistance to sterilization
 - Gamma
 - e-beam
 - Ethylene oxide
- Good melt processability




Optical Transparency of Altuglas® CR30



Light Transmittance

Light Transmittance at 3.2mm Thickness




Optical Transparency of Altuglas® CR30



Haze

Haze at 3.2mm Thickness




Properties

- Resistance to environmental stress cracking (ESC)
- Good optics
- Resistance to sterilization
 - Gamma
 - e-beam
 - Ethylene oxide
- Good melt processability



Yellowness Index After 40 Kgray Gamma Radiation

Resistance to 40 kGray Gamma Radiation



Altuglas® CR30
Lipid resistant Polycarbonate
Chem.Res. Acrylic-Styrene Multipolymer
Medical Grade Copolyester



Yellowness Index After 40 Kgray Gamma Radiation



Properties

- Resistance to environmental stress cracking (ESC)
- Good optics
- Resistance to sterilization
 - Gamma
 - e-beam
 - Ethylene oxide
- Good melt for easy processing



Melt Processing of Altuglas® CR30




Spiral Flow @ 460F / 238C – 2 mm Channel Depth

- Well suited for injection molding processes
- Excellent shear-thinning properties
 - Ideal for thin-walled and multi-cavity molds




Spiral Flow at 460°F- 2mm channel depth



A Balance of Performance Properties



Radar Graph



Product Comparison Summary



Property	Altuglas® CR30	Medical Grade Acrylic-Styrene Multipolymer	Lipid-Resistant Polycarbonate	Medical Grade Copolyester
Optical Transmittance	E	E	F	E
Optical Haze	E	F	E	E
Gamma Sterilization Resistance	E	G	G	G
Alcohol Resistance	E	G	F	P
Lipid Resistance	E	G	P	P
Melt Processing	G	G	F*	P

**Requires higher temperature*

E = Excellent
G = Good
F = Fair
P = Poor



Summary



- BPA “Some Concern”
- ESC is caused by stress and chemical exposure
- Altuglas® CR30
 - Superior ESC resistance
 - Excellent optics
 - Excellent Gamma sterilization resistance
 - Good melt processability



Position Products & Focus Targets



Chemical Resistance

Altuglas[®] CR30



High Flow

Altuglas[®] SG7, Altuglas[®] SG10



UV Transmitting

Altuglas[®] VS-UVT



Altuglas[®] Product Selection

Comparative Advantages




High Flow Grades



Achieving Balance of Properties with Altuglas® SG series Medical Resins

- Excellent Melt Processability
- Excellent Optical Properties
- Outstanding Gamma Resistance
- Good Chemical Resistance
 - Lipid and IPA Resistance
 - Acids and Bases
 - Disinfectants
 - Antiseptics





High Flow Grades



Melt Processing

- **Altuglas® SG10** and **Altuglas® SG7** Medical Resins are high flow resins
 - Perfect resin for thin-walled and multi-cavity mold applications
 - Faster cycle times and/or lower processing temperatures possible
 - Provides good chemical resistance

MFI - 230°C (450°F) / 3.8kg




High Flow Grades




Optical Transparency

- Altuglas® SG Medical Resins provide exceptional optical transparency with a combination of high light transmission and low haze level.

Light Transmittance at 3.2mm Thickness



Haze at 3.2mm Thickness




High Flow Grades

Resistance to Gamma Sterilization

- Devices exposed to gamma sterilization must retain excellent color, clarity, and transparency
- **Altuglas®** SG Medical Resins quickly recover all optical properties and retain 90 -100% of mechanical properties

Resistance to 40 kGray Gamma Radiation



* Medical grade polycarbonate is masked to result in a gray tone after irradiation



Gamma sterilization
+ 2 week recovery


Before
Gamma sterilization

High Flow Grades




Resistance to Lipids and IPA *

- Altuglas® SG Medical Resins have good resistance to IPA
- Altuglas® SG10 has excellent lipid resistance in comparison to other high flow medical polymer




Resistance to Lipid (Cremophor® RH40)



Annealed tensile bars exposed to chemical for 24 hrs at 0.5% constant strain

Resistance to 70% IPA




Annealed tensile bars exposed to chemical for 6 hrs at 0.5% constant strain

* Altuglas® SG Medical Resins were tested under milder, lower strain conditions than Altuglas® CR Medical Resins

High Flow Grades



Achieving a Balance of Properties with Altuglas® SG series Medical Resins



Altuglas® Competitive Comparison



	Altuglas® SG7	Altuglas® SG10	Medical Grade Acrylic-Styrene Multipolymer	High Flow Medical grade Acrylic-Styrene
Optical Transmittance	E	E	G	G
Clarity/Low Haze	E	E	F	F
Resistance to Gamma Sterilization	E	E	G	G
Resistance to Alcohol	P	G	F	F
Resistance to Lipids	G	G	F	F
Resistance to Surface Wetting	F	F	F	F
Melt Processing	E	F	P	F
Impact Resistance	G	G	G	G



E = Excellent
 G = Good
 F = Fair
 P = Poor
 / = Not available



Chemical Resistance

Altuglas® CR30



High Flow

Altuglas® SG7, Altuglas® SG10



UV Transmitting

Altuglas® VS-UVT



Altuglas® Product Selection

Comparative Advantages




UV Transmitting Grades



UV Transmission Challenge

- Medical diagnostic applications require excellent transmission in the ultra-violet region
- Altuglas® VS-UVT has considerably higher UV transmission than non-acrylic materials
- Altuglas® VS-UVT has extremely low haze, good dimensional stability, good scratch resistance and high flow for multi-cavity or complex devices
- Examples of Testing:
 - DNA analysis
 - RNA analysis
 - Protein analysis
 - Blood/Body fluid analysis



➔ Chemical Resistant Grades

Altuglas® CR50, Altuglas® CR30

➔ High Flow Grades

Altuglas® SG7, Altuglas® SG10

➔ UV Transmitting Grades

Altuglas® VS-UVT

➔ Altuglas® Product Selection

Comparative Advantages



Altuglas® Medical Resins



- Altuglas® history of innovation, quality, and customer service
- Portfolio approach that focuses on specific market needs and ensures:
 - Robustness for wide range application
 - Balance of properties
 - Balance between price and performance
- Regulatory Compliance: USP Class VI and ISO 10993 Part 4&5
- Zero BPA, plasticizers, lubricants, solvents



Altuglas® Medical Resins



Altuglas® Medical Resins are designed for transparent disposable medical devices

Drug Delivery

- General Care Syringes
 - Oncology Delivery Syringes
 - High pressure Syringes
 - Drug Prefilled Cartridges
 - Drug Prefilled Syringes
- IV & Infusion
 - Fluid control valves
 - Luers
 - Connectors
 - Spikes
 - Filter Housings

Fluid Management

- Renal Cassettes
- Filter Housing
- Reservoirs
- Urine Meter
- Yankauers
- Drainage Tubes
- Pump Housings

Other Devices

- Respiratory Care
 - Aerosol Delivery/Nebulizers
 - Meters for therapy
 - Rigid Masks
 - Filter Housings
- Veterinary Care

Diagnostics

- Cuvettes
- Meters
- Kits
- Labware
- Petri Dishes
- T-Tubes
- Syringes




Altuglas® Product Selection




Optical Properties


Highest Transmission
& Lowest Haze



Light Transmittance and Haze at 3.2mm Thickness



Light Transmittance and Haze at 3.2mm Thickness



Resistance to Gamma Sterilization


Quickest Recovery
& lowest Discoloration

SG Series

CR30

VS-UVT

Resistance to 40 kGray Gamma Radiation



Altuglas® SG7
Altuglas® CR30
Lipid resistant Polycarbonate
Altuglas® SG10
Acrylic-Styrene Multipolymer

Altuglas® Product Selection



Resistance to Lipids and IPA

Chemical
Resistance

CR30


SG10
SG7

VS-UVT




ALTUGLAS
INTERNATIONAL
ARKEMA GROUP

Resistance to 70% IPA



Resistance to Lipid (Cremophor® RH40)



Presentation to Terumo Europe – 3/10/2011

Altuglas® Product Selection



Melt Processing

Best Flow
Characteristics


VS-UVT

SG7
SG10


CR30



Spiral Flow at 238 ° C- 2mm channel depth



MFI - 230°C (450°F) / 3.8kg



Injection Molding Startup Parameters

Altuglas® Grade	Cylinder Temperature				Other Parameters			
	Rear Zone (C°)	Center Zone (C°)	Front Zone (C°)	Nozzle (C°)	Injection Speed	Screw Speed rpm	Back Pressure Psi	Mold Temp (C°)
CR30	216	221	227	221	Medium	50-100	100	66
SG10	221	227	232	227	Medium	50-100	100	71
SG7	216	221	227	221	Medium	50-100	100	66
VS-UVT	182	188	193	188	Medium	50-100	100	54



Altuglas® Product Selection



Impact Strength


Toughness

CR30


SG10

SG7

VS-UVT

Impact Strength (Falling Dart)
at 3.2mm Thickness, 3lb Dart, 14" Radius


Impact Strength (Notched Izod) at 3.2mm Thickness



Altuglas® Product Selection



Relative Standing Amongst the Altuglas® Medical Resins

Best Chemical
ResistanceGreatest
ToughnessQuickest Recovery
& lowest DiscolorationHighest Transmission
& Lowest HazeBest Flow
Characteristics

Summary



- **Relevant Trends in the Market**
 - Environmental Stress Crack (ESC) Resistance
 - BPA - Free
- **Overview of *Altuglas*® Medical Resins**
 - *Altuglas*® CR30
 - **Outstanding chemical resistance**, excellent optics, gamma sterilization resistance and good melt flow for harsh chemical exposure such as ***Fluid Management & IV and Drug Delivery applications***
 - *Altuglas*® SG Grades
 - Good chemical resistance, excellent optics, gamma sterilization resistance and **exceptional melt flow** for ***Fluid Management and some diagnostic applications***
 - *Altuglas*® VS-UVT
 - **UV transparent** for ***diagnostic applications***





Thank You!

Q & A

Contact Info:

Matt Crans

Email: matthew.crans@altuglasint.com

Office: +33 (0)1 78 66 23 50

Mobile: +33 (0)6 21 57 10 02





The statements, technical information and recommendations contained herein are believed to be accurate as of the date hereof. Since the conditions and methods of use of the product and of the information referred to herein are beyond our control, Arkema expressly disclaims any and all liability as to any results obtained or arising from any use of the product or reliance on such information; NO WARRANTY OF FITNESS FOR ANY PARTICULAR PURPOSE, WARRANTY OF MERCHANTABILITY, OR ANY OTHER WARRANTY, EXPRESS OR IMPLIED, IS MADE CONCERNING THE GOODS DESCRIBED OR THE INFORMATION PROVIDED HEREIN. The information provided herein relates only to specific product designated and may not be applicable when such product is used in combination with other materials or in any process. The user should thoroughly test any application before commercialization. Nothing contained herein constitutes a license to practice under any patent and it should not be construed as an inducement to infringe any patent, and the user is advised to take appropriate steps to be sure that any proposed use of the product will not result in patent infringement.


See MSDS for Health & Safety Considerations

© 2011 Arkema. All Rights Reserved

Altuglas®, SolarKote®, Tuffak®, Kynar®, Rilsan®, Luperox®, Certincoat®, Evatane®, Lotader®, Orevac® are registered trademarks of Arkema



Appendix: Glossary

Term	Definition
Lipid	Natural oil-soluble compound. Include fats, oils, waxes, cholesterol, triglycerides, etc.
Cremophor®	Polyethoxylated lipid , widely used pharmaceutically for solubilization of water-insoluble drugs and vitamins. This class of lipids is known to be aggressive towards transparent plastics Cremophor® EL = Polyethoxylated castor oil. Cremophor® RH40 = Polyethoxylated hydrogenated castor oil.
Intralipid®	Lipid emulsion (also called fat emulsion) for IV administration, as a source of calories and essential fatty acids. Intralipid® 20% = 20% soybean, 1.2% egg yolk phospholipids, 2.25% glycerin, in water.
TPN solution	Total Parenteral Nutrition solution for IV administration, as a source of sugar, proteins, vitamins, and minerals.
IPA	Isopropyl alcohol = Disinfectant = Antimicrobial agent applied to non-living objects
Betadine®	Povidone iodine = Antiseptic = Antimicrobial agent applied to living objects
Hibiclens®	Chlorohexidine gluconate 4% = Antiseptic = Antimicrobial agent applied to living objects
Butylamine	Organic compound used to mimic a functional group of proteins
Chemical resistance	Ability of a plastic to maintain performance upon exposure to chemicals under stress. Loss of performance includes: crazes (or cracks), loss of mechanical strength
ESC resistance	Environmental Stress Cracking resistance = Other used term for "Chemical resistance"
% Elongation retention	This property is related to the retention of mechanical strength after chemical exposure under stress.  % Elongation (% Tensile elongation at break) = Amount that a plastic part can stretch before it breaks during a tensile test. % Elongation retention = % Elongation after chemical exposure compared to unexposed sample.

Glossary-continued

Term	Definition
Chemical Build-up	Accumulation of a chemical substance on the surface of a plastic material. Can potentially lead to clogging of IV lines, and to dosage issues with drug delivery
Spiral Flow	Length of spiral mold that can be filled with a resin in an injection molding process. Higher spiral flow means better melt processing.
Gamma radiation sterilization	Sterilization = Process that effectively kills micro-organisms. Gamma radiation is 1 of the most used sterilization process for medical devices. Other common sterilization processes include: Electron beam, Ethylene oxide (EtO), steam.
kGrays or kilograys	Unit of gamma radiation - 1kGray = 0.1 Mrad (MegaRad) 25 kGrays (2.5 Mrad) of gamma radiation is typical for gamma sterilization
Bonding (or welding)	Bonding (or welding) = Creating a joint between 2 plastic parts Welding techniques include: ultrasonic, Radio frequency, hot plate, solvent
Rockwell Hardness	Measure of a plastic surface hardness by the depth of penetration of an indenter under a load. Different Rockwell scales exist based on different indenters and different loads

