

# Nilamid A3 H7 G10 Processing guide



Nilit Plastics Division

INTEGRATED - PROFESSIONAL - COMMITTED - PARTNERS - RELIABLE - SOLUTIONS - RESEARCH - COOPERATION - SMART - INNOVATIVE - CHALLENGES - CONSISTENT - CREATIVENESS - FRIENDS



-IONet-

## PROCESSING GUIDE NILAMID A3 H7 G10

**Nilamid A3 H7G10** is a 50% glass fibre reinforced PA66 with outstanding resistance against heat aging up to 140 °C. This product combines superb mechanical and thermal performance with ease of processing.

Before processing this material, please read the safety data sheet and this processing guide carefully.

Nilamid A3 H7 G10 is an easy to mould material, which can be processed on most standard injection moulding equipment.

### Pre-drying

Nilamid A3 H7 G10 is hygroscopic and moisture sensitive, so pre-drying is recommended as a matter of rule. Material that is not pre-dried to a moisture level below 0.1% will degrade, causing surface defects, parts that are out of dimension and brittle parts. It is recommended to dry material for 4 hours at 80 °C to 85 °C in a desiccant dryer with more than one desiccant element.

A few tips to ensure proper operation of the dryer:

- Ensure the thermocouple that regulates the temperature is placed immediately before the entry of the air into the dryer. There can be a significant temperature drop in the air-conveyance system!
- The temperature of the air going out of the dryer silo should not be more than 30 °C lower than the air entering the system. If this is the case, you have insufficient air capacity.
- From time to time, monitor the dew point of the dry air to ensure the desiccant elements are functioning properly.

Often, less air runs through the very bottom part of a dryer silo. Therefore, it is recommended that you take the material out of the bottom of the dryer and feed it back into the top when you start up your process.

### Moulding temperatures

For Nilamid A3 H7 G10, the melt temperature must be kept below 300 °C. Any higher temperature will cause rapid degradation, which can be recognized by foaming of the material or splash marks on the surface of the part.

The following barrel settings are recommended:

Material	Zone 1 (hopper)	Zone 2	Zone 3	Zone 4 (Nozzle)
Nilamid A 3 H7 G10	270-290 °C	275-290 °C	285-300 °C	285-300 °C

The recommended melt temperature ranges from 280 to 300°C.

## PROCESSING GUIDE NILAMID A3 H7 G10

### Tool temperature

Mould temperature is always a compromise. On the one hand, tool temperature should be as high as possible to give optimum crystallization and dimensional, optimal surface finish and optimal mechanical performance. On the other hand, lower tool temperature can significantly cut cycle time. For Nilamid A3 H7 G10, 90 °C should be maintained as a minimum, for reinforced grades values of 100 to 120 °C are preferred.

### Pressure and speed

Injection pressure should generally be around 70 to 100 MPa; this results in a minimum clamping force of the moulding machine in tonnes of 0.7 times the projected surface area in cm<sup>2</sup>.

Holding pressure is generally in the area of 90 MPa.

For Nilamid A3 H7 G10, the screw speed should be kept low, a rough indication is as follows:

Screw Diameter (mm)	Maximum rpm
20	150
30	100
40	70
50	60
60	50
70	40
80	35
>80	30

Back pressure should be kept to a practical minimum

### Use of regrind

Parts have been moulded successfully with regrind levels of up to 30%. When regrind is used, observe these simple rules:

- Use a constant ratio of regrind and virgin material. When a material has been processed once, its viscosity and fibre length have been decreased. Using varying ratios of regrind can lead to variations in dimensions, mechanical performance and processing characteristics.
- Either feed the regrind straight back into the machine, or pre-dry the regrind before usage.
- Store regrind in a dry, clean place to avoid contamination and excess moisture.
- Ensure sharp cutting blades to keep dust generation to a minimum; cut glass fibre reinforced material when it is still hot.



## PROCESSING GUIDE NILAMID A3 H7 G10

### Special instructions

- Always pre-dry the material and any regrind that is not fed back immediately into the machine to below 0.1% moisture
- Keep the melt temperature below 300 °C, particularly in areas where long residence times may occur, like hot runners
- When the machine is stopped, purge with PE or a suitable purging compounds. Do not leave the material standing for longer than 30 minutes without purging

Contacts: visit [www.nilit.com/plastics/contacts.asp](http://www.nilit.com/plastics/contacts.asp)

The information given in this document is based on our latest knowledge and we believe it to be accurate. The information is to be used as a guideline only, at your own risk and discretion. We can not assume liability in connection with its use or with the use of the products described in this manual. None of the information is to be taken as a license to operate under, or a recommendation to infringe any patents. Nilamid is a registered trademark of Euronil and is registered throughout Europe. The mark is not registered in the US and no products are sold by Euronil under this name in the US